

MAXIMUM COMFORT AND CONTROL IN HEATING

## **TSSHHC-3IL-Sensor**

The TSSHHC-3IL-Sensor is a remote sensor to be used with the 3IL Thermostat that has the connection for a floor sensor. To use this sensor you will connect it to where the floor sensor connection is located on the back of the thermostat.

